




1) Cable socks can be easily cut to the required length with scissors



2) Do not leave ends unsealed after cutting, as they may fray

3) The ends of the sock can be sealed using a lighter, match or other naked flame to prevent fraying - please use naked flames with care to avoid injury and ensure that this work is only carried out by a responsible adult!

4) The ends of the sock can be secured with string or a cable tie if required to hold the sock in place

